



**DRAWING K:** installation of male end cap

## **IMPORTANT - PRIOR TO INSTALLATION**

**It is important to pre-attach the male end cap to the FIRST u-channel prior to driving. Simply slide in place and fasten with coarse thread deck screws on 24 inch spacing to the u-channel. This will close the open end of the first uchannel and provide a rigid box to drive.**

**To maintain hook spacing, always construct the wall so that the closed end of the uchannel is the leading edge.**

